PLEASE CAREFULLY READ THE SEPARATE HEALTH AND SAFETY PRECAUTIONS BOOKLET INCLUDED WITH THIS PRODUCT BEFORE USING YOUR NINTENDO® HARDWARE SYSTEM, GAME PAK OR ACCESSORY. THIS BOOKLET CONTAINS IMPORTANT HEALTH AND SAFETY INFORMATION.

IMPORTANT SAFETY INFORMATION: READ THE FOLLOWING WARNINGS BEFORE YOU OR YOUR CHILD PLAY VIDEO GAMES



- Some people (about 1 in 4000) may have seizures or blackouts triggered by light flashes or patterns, such as while
 watching TV or playing video games, even if they have never had a seizure before.
- Anyone who has had a seizure, loss of awareness, or other symptom linked to an epileptic condition should consult
 a doctor before playing a video game.
- Parents should watch when their children play video games. Stop playing and consult a doctor if you or your child have any of the following symptoms:

Convulsions
Altered vision

Eye or muscle twitching Involuntary movements Loss of awareness Disorientation

To reduce the likelihood of a seizure when playing video games:

- 1. Sit or stand as far from the screen as possible.
- 2. Play video games on the smallest available television screen.
- Do not play if you are tired or need sleep.
- 4. Play in a well-lit room.
- 5. Take a 10 to 15 minute break every hour.

MARNING - Repetitive Motion Injuries and Eyestrain

Playing video games can make your muscles, joints, skin or eyes hurt after a few hours. Follow these instructions to avoid problems such as tendinitis, carpal tunnel syndrome, skin irritation or eyestrain:

- Avoid excessive play. It is recommended that parents monitor their children for appropriate play.
- Take a 10 to 15 minute break every hour, even if you don't think you need it.
- If your hands, wrists or arms or eyes become tired or sore while playing, stop and rest them for several hours before playing again.
- If you continue to have sore hands, wrists or arms or eyes during or after play, stop playing and see a doctor.

WARNING - Battery Leakage

Leakage of battery acid can cause personal injury as well as damage to your Game Boy. If battery leakage occurs, thoroughly wash the affected skin and clothes. Keep battery acid away from your eyes and mouth. Leaking batteries may make popping sounds.

To avoid battery leakage:

- Do not mix used and new batteries (replace all batteries at the same time).
- Do not mix alkaline and carbon zinc batteries.
- Do not mix different brands of batteries.
- Do not use nickel cadmium batteries.
- Do not leave used batteries in the Game Boy. When the batteries are losing their charge, the power light may become dim, the game sounds may become weak, or the display screen may be blank. When this happens, promptly replace all used batteries with new batteries.
- Do not leave batteries in the Game Boy or accessory for long periods of non-use.
- Do not leave the power switch on after the batteries have lost their charge. When you finish using the Game Boy, always slide the power switch OFF.
- Do not recharge the batteries.
- Do not put the batteries in backwards. Make sure that the positive (+) and negative (-) ends are facing in the
 correct directions. Insert the negative end first. When removing batteries, remove the positive end first.
- Do not dispose of batteries in a fire.

The official seal is your assurance that this product is licensed or manufactured by Nintendo. Always look for this seal when buying video game systems, accessories, games and related products.

Nintendo does not license the sale or use of products


THIS GAME PAK WILL WORK ONLY WITH THE GAME BOY® ADVANCE OR NINTENDO DSTM VIDEO GAME SYSTEMS.

NEED HELP PLAYING A GAME?

Nintendo's game pages, at www.nintendo.com/games, feature walkthroughs, frequently-asked questions, and codes for many of our games. If your answer isn't there, check out our forums where you can exchange tips with other gamers online.

For more information about our forums, visit www.nintendo.com/community.


If you prefer to use your phone, recorded tips for some of our hottest games are available on our Power Line at (425) 885-7529. This may be a long-distance call, so please ask permission from whoever pays the phone bill.



without the Official Nintendo Seal.

© 2005-2006 NINTENDO/GAME FREAK INC. ALL RIGHTS, INCLUDING THE COPYRIGHTS OF GAME, SCENARIO, MUSIC AND PROGRAM, RESERVED BY NINTENDO AND GAME FREAK INC. TM, ® AND GAME BOY ADVANCE ARE TRADEMARKS OF NINTENDO. © 2006 NINTENDO.





ABOUT THE RUMBLE PANS FEATURE

This game includes a built-in Rumble Pak™. Please read the following information before you play the game with the Rumble feature enabled.

The Rumble Pak includes built-in features that rumble while you play, providing realistic feedback.

TROUBLESHOOTING

The Rumble Pak is making a sound.

— When the Rumble Feature is on, the Rumble Pak will make sounds during game play.

Does not rumble

- Make sure the Rumble Feature is turned on in the game (see page 17 for more information on how to set the Rumble Feature).
- Make sure the edge connector of the Rumble Pak and the Nintendo Game Boy Advance system are not dirty.
 Does not stop rumbling
- Make sure the edge connector of the Rumble Pak and the Nintendo Game Boy Advance system are not dirty.

If the Rumble Pak still does not work properly after following these troubleshooting measures, please call Nintendo customer service at 1-800-255-3700.

HOW TO PLAY

When playing the game on the Nintendo DS,
Nintendo Game Boy Advance SP, or the
Nintendo Game Boy Player, please read the
instruction manual of each system.



- Spin your drill counter-clockwise.
- Shift up (while drilling).

+GONTROL PAD

- Move the cursor.
- Press left or right to walk.
- Press down to crouch.

1 SELEGT

Display the Equipment screen (see pg.21 for more information).

- * Press the A Button, B Button, and START to reset the game.
- * Please refer to pages 8-13 for more information on controls.










DRILLING

Jill's Drill Dozer is equipped with two powerful drills. Use them to plow through anything in your way!



SPIN DRILL Ror L Button







REGUIL

R Button → L Button

Spin your drill and quickly reverse the drill's direction to recoil backwards. For example, press the R Button to spin the drill and then press the L Button.





SHIFT UP

R or L Button








Shifting up to the next gear dramatically increases your Drill Dozer's destructive power.
Search for gearboxes and drill into them to get the gear inside.



The drill gauge will fill as you spin your drill. Keep spinning your drill until "SHIFT UP!" appears on the screen.





"SHIFT UP!", release the button for a split second and then press it again to shift up.



BASIG MOVES

The Drill Dozer is a devastating piece of hardware that can pull off some incredible moves. Take the time to learn them all!



WALKING AND CROUCHING +Control Pad

Press the +Control Pad left or right to walk. Press the +Control Pad down to crouch.





DASH

Press + Control Pad down + A Button

Press down on the + Control Pad to crouch, and then press the A Button to dash along the ground.





JUMP

A Button

Press the A Button to jump. The height of your jump depends on how long you hold down the A Button.





ACTION

B Button

Press the B Button when the B Button symbol appears above you to open doors, read signs, push switches, and perform other actions. You can also press the +Control Pad up or down while holding down the B Button to scout out the area around you.









DRILL SURLES

Use these advanced maneuvers in your fight against the skullkers!



DRILLING

R Button or L Button

While you drill into a block on the ceiling or hovering in the air, you'll stay up in the air as long as the drill is spinning.





KICK BACK R Button - L Button

Reverse the drill while drilling into a block to perform a kick, back move and fly backwards. For example, press the L Button to drill into a block, and then press the R Button to kick back.





SKIPPING GAPS R or L Button & + Control Pad

Press and hold the +Control Pad in the direction you're drilling into a block to plow forward to the next block when it crumbles.





DEFLECTING R Button or L Button

Use your drill to deflect enemy bullets. Beware: some enemies attack with weapons that can't be deflected, such as a bomb.






STARTING THE GAME

The health and safety screen will appear when you turn on the power. Once you've read the information, press any button to advance to the title screen.

A HARNING-HEALTH AND SRFETY

BEFORE PLAYING READ THE HEALTH AND SAFETY PRECAUTIONS BOUKLET FOR IMPORTANT INFORMATION ABOUT YOUR HEALTH AND SAFETY

TO GET AN EXTRA COPY FOR YOUR REGION 60 ONLINE AT HINN DIDTERIOD COM/healthsafety/





SAVE SELECTION

Press START on the title screen to access the save-selection screen.
Here, you can access your saved games.



Playing for the first time

The first time you play, select New Game.



Choose the save game you want to resume.

Changing game settings

You can change the following settings in the menu located below the save data. Follow the instructions on the screen to make adjustments.

Copy / Erase

You can copy or erase saved data. When copying data, choose the data you want to copy and then select where you want to copy it to. When erasing data, select the data you want to erase.

Sound


Choose between mono or stereo sound.

Rumble Feature

Choose on or off.

Saving your progress

You can save your progress on the Save screen. See for more information.



Rumble Feature!

Be careful! If you erase saved data, it's gone forever!



PRAMING THE GAME


Take control of Jill's powerful Drill Dozer and demolish your way through area after area packed with enemies!



STAGE SCREEN



Use all of the moves at your disposal to make your way to the end of the area. Just touch an item to grab it. See _____ for more information.



Gears

Find gears to gain the ability to shift up! See will for more information.

Energy

The Drill Dozer's energy bar will fall every time you take damage.

Touch treasure chests to get the loot inside! See the formore information.

Treasures



SHIFT UP!

When you find a gear, the Drill Dozer will be automatically upgraded with the ability to shift up. The Drill Dozer can carry up to three gears. Due to wear and tear, you will lose all of your gears when you complete an area.








GAME OVER

Your game is over when you run out of energy. However, you can pay 50 Chips to continue See for more information.





If you find a strange device, try using your drill to activate it.



Chips come in handy at critical moments!





TRAILER

You will be taken back to the trailer every time you complete an area. There, you can buy upgrades, view your treasures, save your game, and more!



GETTING AROUND THE TRAILER

Each character in the trailer has a different area of the trailer.

Select a character with the +Control Pad and press the A Button to move to that area.





MAP

Here, you can choose the area you want to travel to. First select the area, and then choose the stage in that area you want to enter. Select the Red Dozers' Training Course to practice your skills.





EQUIPMENT



Your Drill Dozer's current equipment will be displayed here. You can also view this screen by pressing SELECT during play.




Drill Bit	The drill bit you currently have equipped.
Drill Type	View the drill type you have equipped. Sometimes, you can use special equipment.
Gears	The gears you have equipped.
Energy	The current and maximum energy capacity of your Drill Dozer.
Chips	The number of Chips you have collected.



Press the A Button to view the help screen. Use the + Control Pad to select a subject, then press A to view it.













Go here to see a list of treasures you've found. Use the +Control Pad to select a treasure and view its description







option from the menu below. You can also reach this screen by pressing START while you play.



Save Save your progress.

Put your Game Boy Advance system in sleep mode. Press SELECT while holding Sleep down both the L and R Buttons to wake up your system.

Return to the trailer. This option only appears when you're in an area.

Exit





The shop will only appear after you've progressed a ways into the game. Here, you can spend your hard-earned Chips to buy items and upgrades. See the for more information.



Collect treasures!

Treasure chests have been hidden all over the world. It's up to you to find them! They're often hidden in hard-to-reach places. Sometimes, you may even need a more powerful drill bit to get to them! Can you collect all of the treasures in an area?











Some helpful hints are listed below. Be sure to check the help file (see for more into) to learn how to use them.

GRACKED WALLS





EQUIPMENT FOR EVERY OCCASION

As you play the game and find more equipment, you'll be able to operate underwater and even fly in the air!









GOLLECT ITEMS

Smash open item blocks with your drill to find items. You can spend Chips at the shop to get items, too! Items you can find in an area.



Energy

Recovers your energy. How much you recover depends on the size.

O Chips

Spend chips at the shop to get new items and upgrades!

Items you can buy at the shop.

Increases your maximum energy level. **Energy Tank**

This strong drill bit can crush solid rock. Super Bit

The most powerful drill bit. It can smash even the hardest rocks! Mega Bit

A new area will appear in the map room. Maps





DIRECTOR KEN SUGIMORI

CHARACTER DESIGN HIRONOBU YOSHIDA

LEAD PROGRAMMER SOHSUKE TAMADA

MUSIC & SOUND EFFECTS
GO ICHINOSE
SATOSHI NOHARA

AKIHITO TOMISAWA KENJI MATSUSHIMA SACHIKO HAMANO HIRONOBU YOSHIDA NAOKO YANASE

SATOSHI NOHARA

PROGRAMMING

KEITA KAGAYA YOSHINORI MATSUDA DAISUKE GOTOH MASAO TAYA SATOSHI NOHARA HISASHI SOGABE

GRAPHIC DESIGN
HIRONOBU YOSHIDA
MOTOFUMI FUJIWARA
TAKAO UNNO
HIROKI FUCHINO
KENKICHI TOYAMA

CAME DESIGN
KEN SUGIMORI
KENJI MATSUSHIMA
TADASHI TAKAHASHI
TETSUJI OHTA
TERUYUKI SHIMOYAMADA
SHIGERU OHMORI

ADDITIONAL TUNING
SHIGERU OHMORI
JUNICHI MASUDA
TAKESHI KAWACHIMARU

TETSUYA WATANABE
AKITO MORI
HIROYUKI NAKAMURA
TOMOMICHI OHTA
MIYUKI IWASAWA
NOZOMU SAITOH

TOMOYA TAKAHASHI SUPER MARIO CLUB

DEBUG SUPPORTSHUICHI NARUSAWA

SPECIAL THANKS
TSUNEKAZU ISHIHARA
YUURI SAKURAI
HIROMI SAGAWA
YUMI FUNASAKA
NAOKO YANASE

PROJECT MANAGEMENT HITOSHI YAMAGAMI AZUSA TAJIMA

PRODUCER
JUNICHI MASUDA

SATOSHI TAJIRI

SATORU IWATA
GAME FREAK inc.
NINTENDO CO., Ltd.

THOMAS CONNERY REIKO NINOMIYA ERIK PETERSON

LOCALIZATION
MANAGEMENT
NATE BIHLDORFF
JEFF MILLER
LESLIE SWAN
BILL TRINEN

NOA TESTING DEPT.
(NOA Product Testing Staff)
YOSHINOBU MANTANI
SHUJI HASHIMOTO
ROB CROMBIE

KYLE HUDSON
ERIC BUSH
SEAN EGAN
JIM HOLDEMAN
MIKA KUROSAWA
TERESA LILLYGREN
TOMOKO MIKAMI
PATRIK TAYLOR

PACKAGE & MANUAL HITOMI ROSS





IMPORTANT LEGAL INFORMATION:

Copying of any video game for any Nintendo system is illegal and is strictly prohibited by domestic and international intellectual property laws. "Back-up" or "archival" copies are not authorized and are not necessary to protect your software. Violators will be prosecuted.

This Nintendo game is not designed for use with any unauthorized copying device or any unlicensed accessory. Use of any such device will invalidate your Nintendo product warranty. Nintendo (and/or any Nintendo licensee or distributor) is not responsible for any damage or loss caused by the use of any such device. If use of such device causes your game to stop operating, disconnect the device carefully to avoid damage and resume normal game play. If your game ceases to operate and you have no device attached to it, please contact Nintendo Customer Service (see below).

The contents of this notice do not interfere with your statutory rights.

This booklet and other printed materials accompanying this game are protected by domestic and international intellectual property laws.

For further information or assistance, please contact: Nintendo Consumer Service www.nintendo.com or call 1-800-255-3700 (U.S. and Canada)

WARRANTY AND SERVICE INFORMATION

You may need only simple instructions to correct a problem with your product. Try our website at www.nintendo.com or call our Consumer Assistance Hotline at 1-800-255-3700, rather than going to your retailer. Hours of operation are 6 a.m. to 7 p.m., Pacific Time, Monday - Sunday (times subject to change). If the problem cannot be solved with the troubleshooting information available online or over the telephone, you will be offered express factory service through Nintendo. Please do not send any products to Nintendo without contacting us first.

HARDWARE WARRANTY

Nintendo of America Inc. ("Nintendo") warrants to the original purchaser that the hardware product shall be free from defects in material and workmanship for twelve (12) months from the date of purchase. If a defect covered by this warranty occurs during this warranty period, Nintendo will repair or replace the defective hardware product or component, free of charge. The original purchaser is entitled to this warranty only if the date of purchase is registered at point of sale or the consumer can demonstrate, to Nintendo's satisfaction, that the product was purchased within the last 12 months.

GAME & ACCESSORY WARRANTY

Nintendo warrants to the original purchaser that the product (games and accessories) shall be free from defects in material and workmanship for a period of three (3) months from the date of purchase. If a defect covered by this warranty occurs during this three (3) month warranty period, Nintendo will repair or replace the defective product, free of charge.

SERVICE AFTER EXPIRATION OF WARRANTY

Please try our website at www.nintendo.com or call the Consumer Assistance Hotline at 1-800-255-3700 for troubleshooting information and repair or replacement options and pricing. In some instances, it may be necessary for you to ship the complete product, FREIGHT PREPAID AND INSURED FOR LOSS OR DAMAGE, to Nintendo. Please do not send any products to Nintendo without contacting us first.

WARRANTY LIMITATIONS

THIS WARRANTY SHALL NOT APPLY IF THIS PRODUCT: (a) IS USED WITH PRODUCTS NOT SOLD OR LICENSED BY NINTENDO (INCLUDING, BUT NOT LIMITED TO, NON-LICENSED GAME ENHANCEMENT AND COPIER DEVICES, ADAPTERS, AND POWER SUPPLIES); (b) IS USED FOR COMMERCIAL PURPOSES (INCLUDING RENTAL); (c) IS MODIFIED OR TAMPERED WITH; (d) IS DAMAGED BY NEGLIGENCE, ACCIDENT, UNREASONABLE USE, OR BY OTHER CAUSES UNRELATED TO DEFECTIVE MATERIALS OR WORKMANSHIP; OR (e) HAS HAD THE SERIAL NUMBER ALTERED, DEFACED OR REMOVED.

ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED IN DURATION TO THE WARRANTY PERIODS DESCRIBED ABOVE (12 MONTHS OR 3 MONTHS, AS APPLICABLE). IN NO EVENT SHALL NINTENDO BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE BREACH OF ANY IMPLIED OR EXPRESS WARRANTIES. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR EXCLUSION OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state or province to province.

Nintendo's address is: Nintendo of America Inc., P.O. Box 957, Redmond, WA 98073-0957 U.S.A.

This warranty is only valid in the United States and Canada.

NEED HELP WITH INSTALLATION, MAINTENANCE OR SERVICE?

NINTENDO CUSTOMER SERVICE WWW.NINTENDO.COM

or call 1-800-255-3700

MON. - SUN., 6:00 a.m. to 7:00 p.m., Pacific Time

(Times subject to change)





Nintendo of America Inc.

P.O. Box 957, Redmond, WA 98073-0957 U.S.A.

www.nintendo.com